

Instructions for attaching Ocutech VES systems to the NEW slotted NOIR design

The new design of the slot for NOIR filters is intended to wrap tightly around the telescope to minimize light leak and allow for a full range of telescope positioning.



1. The new slotted design allows the VES system to be inserted from the top



2. Tilt the telescope so that the side opposite from the eyepiece slides in front of the NOIR filter.



3. Straighten the telescope so that the eyepiece positions into the notch at the bottom of the slot.

